

FIG. 1







FIG. 2



G. 3A



G. 3B








FIG. 5




FIG. 6

40

634-3

TAPE MAP NO 25

629 SELECT ; DECIDE ; /

634 1 2 3 4 5

PROGRAM NUMBER	MONTH/DATE	DAY OF THE WEEK	CHANNEL	START	MINUTE	
Z 630 1	9/24	FRIDAY	4	AM 9 : 00	120	EP
X 2	10/10	SUNDAY	1	PM 8 : 15	15	EP
631 3	10/ 1	WEDNESDAY	12	PM 8 : 00	55	EP
632 4	9/30	THURSDAY	BS11	PM10 : 00	150	EP
Y 633 5	BLANK		* 20 MIN *			

FIG. 7





FIG. 8



TAPE MAP
BUTTON
141

ORDINARY
PICTURE

"PLAY-BACK" BUTTON 143

PROGRAM SEARCH 60

PROGRAM BEING SEARCHED PROGRAM NO.2

C1 PLAY-BACK

"PLAY-BACK" AFTER PROGRAM SEARCH

"STOP" BUTTON 145

PROGRAM SEARCH 62

PROGRAM BEING SEARCHED PROGRAM NO.2

C1 STOP

FIG. 9




FIG. 10




FIG. 11

